

SRX

SIMRACING REAL XPERIENCE



SRX SCR DASH

User manual

SRX SCR DASH



AVAILABLE FOR:

- FANATEC CSW & CSL
- ACCUFORCE
- OSW
- OTHERS



SIMRACING REAL XPERIENCE

TABLE OF CONTENTS

Getting Started.....	4
How to install.....	4
Software of Symprojects.com	5
Control buttons.....	10
Led Light	10
Other products	11

Welcome to the world of SimRacing Real Xperience

GETTING STARTED

First we want to thank you for your reliance on SRX, we expect our products to your liking.

Here we will explain you how to operate your new SRX SCR DASH, are three very simple steps that once completed will make you enjoy a new level in the SimRacing.

Our design SCR DASH, consists of two parts:

- Control buttons for your simulation experience.
- Display of information that immerses you in the experience of the competition.

With the collaboration of SYMPROJECTS.COM, we have managed to our product is easy to install.

Below we show you how to do it.

HOW TO INSTALL THE SCR DASH ON FANATEC CSW

To install your SCR DASH at the base FANATEC CSW (V1 or V2), CSL, you must remove the screws shown in the picture.




Then you put the SCR DASH of leaving the base in the hollow of the dashboard, to match the holes, then you Put the four screws.




SOFTWARE OF SYMPROJECTS.COM


You have to download the software Symprojects.com, you will find in <http://www.symprojects.com/wp-content/SimDash.zip>, with this software you can configure the operation of your SCR DASH Leds, this setting is made by SRX, and you just have to import it.




-Once installed you must click Configure in the box Pro Shift.




After you must click on IMPORT.





And a browser window will open, you must select the configuration file that you obtained from SRX after making the purchase of your SCR DASH (SRX SCR Dash.xml).




Once selected you click on open and the configuration will be loaded, after you click on ok.



You can configure the XML selecting the option you want to change and then clicking the diferents options on Blinkink or RPM percentage:



To save the changes you must export the file, you can overwrite the existing, or create a new one with a different name.



CONTROL BUTTONS

Settings control buttons is plug and play and is done through the game settings.

LED LIGHT

The illumination of your new SCR DASH is long lasting LED, find a remote control your lighting SCR DASH and operation manual.



OTHER PRODUCTS

INNOBOX PRO



INNOBOX BASIC



GENUINE PRO




GENUINE BASIC



CUSTOM DASH



ACCESSORIES



SUPPLIES

CUSTOMER CARE

www.simracingxperience.com



mail:

support@simracingxperience.com

CONTENT

1. CSW SCR DASH.
2. USB CABLE 5 m.
3. RGB CONTROLLER.
4. Supply 12V.
5. User manual.



Visit us on the Web
www.simracingxperience.com